

MASTERBUILT®

Bottom Hopper Kit, GSGXT







MB20041223, MB20043024



CAUTION

- Always remove plug from outlet before servicing your grill.
- Make sure your grill has fully cooled to avoid burns.
- Some components may have sharp edges. Use caution to avoid injury.

Note: Your grill may vary from images shown

		
<p>Remove the fan from the lower housing, you will reuse (4 Screws).</p>	<p>Remove the bottom hopper shrouds and hopper door (10 Screws).</p>	<p>Remove the charcoal grate and ash bucket from the hopper.</p>
		
<p>Remove hardware from the bottom shutdown flap assembly.</p>	<p>Remove the switch (2 Screws) and the (10 Screws) holding the bottom hopper.</p>	<p>Remove the bottom hopper.</p>

For installation, follow all steps in reverse.