

MASTERBUILT®

Gravity Universal Controller Antenna Kit Replacement

GSG 560, GSG 600, GSG 800, GSG 900, GSG 1050, GSG 1150



CAUTION




- Make sure the grill has cooled completely before handling to avoid burns.
- Some components may have sharp edges. Use caution and wear protective gloves to avoid injury.
- Power OFF the grill and disconnect the power from the wall before handling.

Replace Controller Antenna for GSG 560, GSG 600, GSG 800, GSG 900 and GSG 1050



1

Remove the failed antenna.



2

Install new antenna.

Replace Controller Antenna for GSG 1150




1

Remove the heat intake slide.




2

Remove 2 screws to detach the controller kit from the hopper.




3

Remove 6 screws from rear of the controller kit to open the back panel.




4


Remove the antenna and wire.



Install new antenna and wire.



Reinstall the back panel of the controller kit.



Reinstall the controller kit on the hopper with 2 screws.



Put the heat intake slide in place.