


# MASTERBUILT®

## Controller Instruction Sheet




### Gravity Fed Grill CGP24G1D, CGP28G1D, CGP30G1D



#### CAUTION



- Always remove plug from outlet before servicing your grill.
- Make sure your grill has fully cooled to avoid burns.
- Some components may have sharp edges. Use caution to avoid injury.



#### INSTALLATION:

- Insert the control panel into the side shelf and tighten the four (4) screws into its back to secure it in place (see step 3).
- Install the antenna by screwing it onto the back of the panel. Then, turn the top portion of the antenna as shown (see step 2).
- Connect the three cords from inside the grill to the digital control panel (see step 1).