




SMOKER SIDE SHELF Model# 20101613



FITS MASTERBUILT MODELS: 20070213, 20070312, 20070512, 20070513, 20070613, 20071214, 20071514, 20071314, 20071414, 20072112, 20072612, 20072912, 20073012,







Tools required for assembly: Phillips Head Screwdriver

- 1** Before installing side shelf **(A)**, the shelf must be disassembled into shelf bracket **(A1)** and shelf **(A2)** by removing only the shelf bracket screws **(B)** on top as shown. *(Shelf shown from below)*
As shelf **(A2)** is slotted, it should easily separate from shelf bracket **(A1)** without having to loosen the other two screws.
- 2** Facing left side of smoker, remove door hinge cover screws **(D)** and door hinge cover **(C)**, then remove left control panel screw **(E)** from control panel housing **(F)**.
- 3** Remove only rear door hinge screws **(G)** *(Do not loosen or remove door hinge screws on the right as the door for smoker will loosen and the seal could be compromised.)*
- 4** Still facing the left side of smoker, remove rear handle screws **(H)** as illustrated, allowing rear handle **(I)** to move freely.
- 5** Install shelf bracket **(A1)** on to smoker body. Bring back end of shelf bracket **(A1)** between smoker body and rear handle **(I)** as shown.
- 6** Secure shelf bracket **(A1)** using washers **(K)**, replacement door hinge screws **(L)** and replacement control panel cover screw **(J)** with the single black washer **(M)**. *(supplied in bag).*
Replace door hinge cover **(C)** and secure with door hinge cover screws **(D)**.
At this time reverse **step 4**, by replacing rear handle screws **(H)** and securing rear handle **(I)** to side shelf and smoker body.
- 7** Align shelf **(A2)** with shelf bracket **(A1)** and re-secure using shelf bracket screws **(B)** *(Do not tighten all the way, shelf should be able to move freely.)*

SMOKER SIDE SHELF INSTALLATION IS NOW COMPLETE.

POSITIONING

- 8 Upright Position**
With both hands on the left and right of the shelf, lift smoker side shelf. When shelf is in full upright position, push the shelf gently towards the smoker. The hinge should then drop and lock into place.
- Downward Position**
Again, with both hands on each side of the smoker side shelf, slightly lift the shelf to remove it from its locked position, then gently pull towards yourself and swing the shelf into it's downward position.



CAUTION

- SMOKER SIDE SHELF WEIGHT CAPACITY 25 LBS.
- NEVER MOVE SMOKER WITH SHELF IN UPRIGHT POSITION.
- DO NOT SIT ON OR LEAN AGAINST SHELF.
- WHEN ADJUSTING SHELF, KEEP FINGERS CLEAR OF HINGES.