

LIGHT YOUR CHARCOAL GRILL WITH THE PUSH OF A BUTTON.

STARTING A CHARCOAL GRILL IS NOW AS EASY AS GAS.

HOW IT WORKS

1

PREHEAT IGNITOR

Press the automatic ignition button on the controller + set temperature. The fan and the ignitor do the rest!

2

LOAD CHARCOAL

Fill hopper with up to 5lbs of Masterbuilt lump charcoal for up to 5 hours of use.

3

LOAD FIRESTARTER

Fold side shelf up, insert fire starter into fire starter holder through lower access door.



CONNECTED GRILLING

Control and monitor your grill from anywhere using the Masterbuilt® app.



CHARCOAL MINIHOPPER™

Holds 5 lbs. of lump charcoal or 7 lbs. of briquettes for up to 8 hours of use.



QUICKSTART™ AUTO-IGNITION

Light fire starter with the push of the QuickStart™ Auto-Ignition button.



SMOKE + SEAR VERSATILITY

Reaches from 250°F to 650°F for low + slow or high heat searing.